





C845 Rivnut® Hand Tool



Rivnut®: (one piece) tubular rivet with internal threads, blind installation provides clean threads for screw attachments

800-236-3200

www.cardinalcomponents.com

ISO CERTIFIED · info@cardinalcomponents.com
All Major Credit Cards Accepted · Fax: 262.252.5033



C845 Rivnut® Hand Tool OPERATING INSTRUCTIONS

Lubricate 5/8" Jackscrew threads before use


Wrench Type Rivnut Fastener Headers are available for Rivnuts with the following thread sizes: 6-32, 8-32, 10-32, 10-24, 12-24, 1/4-20, 1/4-28 Metric sizes M3, M4, M5 & M6

1



Engage all threads of the Rivnut Fastener on the pull up stud. Advance anvil until it is tight on head of Rivnut. Insert Rivnut in hole.

2



Place Hex Wrench in socket of jackscrew & hold stationary. Turn Hex Nut in counter clockwise direction with a wrench while holding tool at right angles to the work.

3

Turn nut the required number of turns - or until firm resistance indicates complete upset of the Rivnut. (a box end ratchet wrench will speed up this operation.)

Rivnut Thread

Approx. Turns Required to Upset
in Min. Grip in Max. Grip


No. 6 & M3	1-1/4	1/2
No. 8 & M4	1-1/2	3/4
No. 10 & M5	1-3/4	1
No. 12	2	1-1/4
1/4" & M6	2-1/4	1-1/2

4

Break nut loose with clockwise movement. Remove both wrenches from the tool



5



Remove tool from Rivnut by revolving entire tool in counter clockwise direction.

Call 800-236-3200

www.cardinalcomponents.com